


A-LINE #X732 4-TIER BAG & TISSUE FLOOR DISPLAY
ASSEMBLY INSTRUCTIONS

PARTS:


1 x Base (NO LONGER TRUMPET BASE AS SHOWN);
 4 X 5-Sided Multi-Prong Tiers
 (stacked on the base in the order of how they will go on display)



PARTS CONT'D:

2 Tubes with pre-drilled holes; 1 sign holder


HARDWARE: 4 X cotterpins (attached to sign holder); bearings and flat washers (not shown) are already placed in between each tier as required for assembly



STEP 1:

**** LEAVE TIERS ON THE BASE AS RECEIVED;**


Take the tube with NO cap at the top and insert into the base; take 2nd tube (with a white cap at the top) and insert into first tube installed on the base




STEP 2: Pull up the first tier sitting at the top on the base (make sure to pick up the bearing and washer with it); Raise up the tube so that tier plus hardware are above the pre-drilled hole at the very top; Take one cotter pin and slide through the holes; hardware and tier will sit on top of the cotter pin - open cotter pin with pliers to secure in place



STEP 3: Repeat Step #2 for the remaining 3 tiers



FINISHED ASSEMBLY WITH SIGN HOLDER AT THE TOP



TOOL REQUIRED FOR ASSEMBLY:
PAIR OF PLIERS TO OPEN THE COTTER PINS TO SECURE THEM IN PLACE

NOTE: IF TIERS ARE REMOVED FROM THE BASE, THE ORDER THEY MUST BE PUT BACK IN IS:
 1ST/TOP TIER = 15 PRONGS
 2ND AND 3RD MIDDLE TIERS = 10 PRONGS
 4TH/BOTTOM TIER = 5 PRONGS